

How can I modify audio settings for a camera?

All camera-related settings can be accessed via the **Cameras** tab of the system manager.

Open the **Camera Settings** pop-up window for the desired camera by clicking the **cogwheel** icon in its row.

Use the **Audio source** and **Audio gain (dB)** drop-down menus to select the audio source and set the gain respectively.



NOTE: In recording audio, gain is the first control that the microphone signal goes through in a mixer.

