

# System Module



**IMPORTANT:** The **System** module is only accessible for users with Admin role.

The **System Manager** provides tools and resources to manage your CAE LearningSpace system.

To access the System Manager, click the **System** tile on the Dashboard. From the System Manager screen, the following tabs are available to manage the CAE LearningSpace system:

- **General** for managing general information and demo users
- **Local Settings** for adjusting time and language options
- **Security** for configuring secure access and server settings
- **Directory Access Settings** for LDAP server setup
- **Emails** for setting up email properties and SMTP server data
- **Intercom** for managing pre-recorded or adding new intercom announcements
- **Rooms** for managing rooms, including assignment of cameras, manikin, intercom devices
- **Simulators** for connecting simulators and wireless bridges
- **Cameras** for configuring and managing cameras
- **Downloads** for selecting available downloads

